




#### 4. Link / Unlink ( B1-B4 & T1- T4 & B1-B/B3-B/B4-B )

##### Linking Instructions


- 
- 1 Switch off the light, after 10 seconds switch on again.
- 2 When the light on, short press any zone of "Link/Unlink" 3 times within 3 seconds.
- 3 The light blink 3 times slowly means the linking is done successfully.

 If the light not blink slowly, the linking failed, pls switch off the light again, and follow the above steps again.

##### Unlinking Instructions

- 
- 1 Switch off the light, after 10 seconds switch on again.
- 2 When the light on, short press "Link/Unlink" 5 times within 3 seconds.
- 3 The light blinking 10 times quickly, means the unlinking successfully.

**Unlinking must be the same zone with the Linking**

 If the light not blink quickly, the unlink failed, pls switch off the light again, and follow the above steps to unlink again.