


# Quick guide to EB-Therm 205

Get started quickly and easily! Here you have a guide to the most important functions and settings, an introduction to the energy saving programs and an overview of the menu system.


Always read the entire manual for complete product information.

## Getting started with EB-Therm

This is what the display looks like when you first start EB-Therm.




## Using the menu




\*Or wait 30 seconds to exit automatically.

## Turning off and on



\*The heat is not being regulated. The clock is running and any settings are saved in the memory.


## Locking the keypad



# Basic settings


## Time and date

To be able to use all the functions you need to set the time and date first.




\*Repeat the last two steps to set minutes, day, month and year.  
The weekday is set automatically but not displayed.

## Desired temperature



## Show actual temperature



\*If the thermostat is set to *Floor thermostat*.  
Otherwise the room temperature (R) is displayed.

**More on temperature** The EB-Therm 205 can regulate the temperature in three different ways; *a floor thermostat, a room thermostat or a room and floor thermostat*. This enables the comfort temperature and any flooring temperature requirements to be combined. If the floor sensor is connected when the thermostat is turned on for the first time, the *floor thermostat* is selected automatically. The *room thermostat* cannot be selected when the floor sensor is connected. The room and floor thermostat should be used in rooms with wooden flooring and in rooms with large windows that are exposed to solar insolation. Read more about the control functions and how you set them in the manual. Actual temperatures can be read at all times by following the above description.

# Energy saving programs

Save energy cleverly and easily! With these programs the heating is adapted to your actual needs and the heat is turned down when it isn't needed. There are two program options:



Preset for home environments

The temperature is automatically reduced by 5°C during the following periods:

Monday-Friday, 8.30am-3pm


Monday-Sunday, 11pm-5am



Program for office environments

The temperature is automatically reduced by 5°C at all times except for Monday-Friday, 6am-6pm



## Start/stop programs



\*Stop program: Confirm when no symbol is flashing.

# Sitemap of the menu

This is how the menu in EB-Therm 205 is structured. Here you can quickly see where all the functions and settings are.

<div><b>CONT</b> Set the display contrast</div> <div>1-8</div>	<div><b>PROG</b> Start/stop programs</div> <div><div> Home programs</div><div> Office programs</div></div>
<div><b>SET</b> Various settings</div> <div><div><div><b>CLK</b> Set time and date.</div><div><b>S</b> Turn off and on automatic change to DST</div><div><b>RNF</b> Set how the temperature is to be regulated. F (floor thermostat) - R (room thermostat) – R &amp; F</div></div><div><div><b>OH</b> Set the temperature to restrict the floor sensor for R &amp; F.</div><div><b>DISP</b> Set how time will be shown, 24- or 12-hour format.</div></div><div><div><b>AF</b> Turn off and turn on the adaptive function.</div><div><b>RST</b> Reverts to factory settings and deletes all personal settings.</div><div><b>END</b> Exit the menu and return to basic mode.</div></div></div>	
<div><b>LOCK</b> Locks the keypad</div> <div></div>	<div><b>END</b> Exits the menu</div> <div></div>